

ISTRUZIONI PRATICHE

AVVIO DEMINERALIZZATORE Minidem 30

Nordacque invita a seguire la procedura di seguito spiegata per garantire il corretto funzionamento del prodotto:

1. Aprire la valvola di sfiato centrale con posizionando la leva in verticale come in *Foto 1*;
2. Alimentare idraulicamente il demineralizzatore;
3. Mantenere aperta la valvola di sfiato fino a quando fuoriesce acqua;
4. Chiudere la valvola di sfiato come in *Foto 2* e collegare l'attacco di uscita;
Ora il demineralizzatore è avviato correttamente.

Nordacque non si riterrà responsabile di eventuali malfunzionamenti del prodotto provocati dal mancato rispetto della procedura indicata.

PRACTICAL INTRUCTIONS

DEMINERALIZATORS Minidem 30 series

Nordacque suggest the following procedure in order to ensure proper operations of the system:

1. Put the central vent valve in upright position (to open) like *Photo n.1*;
2. Hydraulically powered the demineralizers;
3. Keep the vent valve open until water fall out;
4. Put the vent valve in horizontal position (to close) like *Photo n.2* and put-on the outlet connection;
Now the demineralizers is ready to use.

Nordacque will not be responsible for any malfunctions caused by failure to follow this procedure.

Foto n.1 - Photo n.1



Foto n.2 - Photo n.2

